


CB750 LTD



SWITCH CONTINUITY

	W	R	L	P	PR	PL
R	○	○				
N						
L			○			

	HL	Lo	Hi
Lo	○	○	
(N)			
Hi			○

	HO	E
FREE		
PUSH		

	BAT1	IG	TL1	TL2	PA
OFF					
ON	○	○			
P					

	BAT3	HL	BAT2	ST
FREE	○			
PUSH				

	BAT2	IG
OFF		
RUN	○	
OFF		

0030Z-425-8700